


4. Insert relay(s) into desired slot(s).
5. Secure each relay with locking screw.

6. Wire device (e.g., light stack, etc.) to associated relay terminal block (Relay 1 Out, Relay 2 Out, Relay 3 Out).



7. Assemble Scanner.

MICROSCAN


Microscan Corporate Office
Tel 425-226-5700/Fax 425-226-8250

Microscan Europe
Tel 31-172-4233-60/Fax 31-172-4233-66

Microscan Asia Pacific RO
Tel 65-6846-1214/Fax 65-6846-4641

www.microscan.com
Email: info@microscan.com

© 2007 Microscan Systems, Inc.



3. Move header jumpers (J1, J2, J3) from 3-5 to 1-3 and 4-6 to 2-4 for each relay to be installed (K1, K2, K3).

RELAY MODULES

MS-890 Scanner

Using Pluggable Relay Modules

1. Turn off power (if connected).
2. Remove 4 screws attaching scanner to wiring box and lift scanner away from wiring box.

