

HS-21/HS-41X HANDHELD READER CONFIGURATION GUIDE




Hardware Required


Item	Description	Part Number
1	HS-21 Handheld Reader	FIS-HS21-000XG
	HS-41X Handheld Reader	FIS-HS41X-000XG
2	USB Cable, 6' Straight	61-000224-01
	USB Cable, 8' Coiled	61-000224-02
3	RS-232 Cable, 8' Coiled	61-000224-03
4	RS-232 Power Supply, 8' Coiled, U.S.	20-000335-02
	RS-232 Power Supply, 8' Coiled, Euro	20-000336-02
	RS-232 Power Supply, 8' Coiled, UK	20-000337-02

Configuration

USB



RS-232



Accessories

Presentation Stand	98-000153-02	Flexible stand for fixed-mount Motion Detect operation
HS-41X Demo Kit	98-000263-01	HS-41X Handheld Reader, X-Mode, 6' Straight USB Cable
HS-21 Demo Kit	98-000264-01	HS-21 Handheld Reader, Standard, 8' Coiled USB Cable
Microscan Tools Drive	37-000010-01	Software, User Manuals, Quick Start Guides, Configuration Guides, links to Microscan website