Quick Start Guide

Smart Series Ring Bracket

(HAWK MV-4000)

P/N 83-9200055-04 Rev A

Caution: Be sure that all connections are secure BEFORE applying power. Power down BEFORE disconnecting cables.

Important: All specified wire colors apply to Omron Microscan cables. If non-Omron Microscan cables are used, it is the customer's responsibility to make sure the illuminator is connected per the specified connector pin numbers.

1. Mount the ring light to the bracket with the two supplied M3 X 8 mm flat head socket screws as shown. The ring lights can be clocked in 90 degree increments relative to the bracket to best position the cable.

2. Mount the camera bracket to the camera with the two supplied M4 X 8 mm flat head socket screws.

3. Attach the camera bracket and ring light bracket to the rail with the supplied M8 screws as shown.

4. Mounting the assembly:
   A. The assembly can be mounted using the M4 threaded holes on the front of the camera. See the camera documentation for exact hole locations and thread depths.
   B. The assembly can also be mounted via the rail using the two M8 T-nuts and corner brackets.

5. Install the plastic end cap to complete the assembly.

OMRON
MICROSCAN