

# LVS-7510

## 7 Steps to Print Quality Inspection with the LVS-7510



**STEP 1** Label designer creates a label in label design software.

**STEP 2** Label design is checked for barcode grading and data structure using an LVS-9580 off-line verifier.

**STEP 3** Label design is imported into the LVS-7510 via scanning of representative labels.

**STEP 4** Label inspection criteria are established in LVS-7510 software.

**STEP 5** Label inspection template is pushed into production.

**STEP 6** Production runs batch of labels and determines inspection results.

**STEP 7** Based on label production results, adjustments are made to the label design, printing system, or inspection criteria.

